Avaya™ 3606 Wireless IP Telephone Quick Reference Guide

Accessing the Function Menu

Press **FCN** followed by a digit **(1-4**, and ***** or **#)** while off-hook to access the feature options programmed for your Wireless Telephone template.

When you are on a call, your Wireless Telephone display will show a solid number indicating which line you are currently using. If a second call comes in on another line, a flashing second number will appear to indicate which line is ringing.

The Line appearances administered for your extension are displayed by pressing the **LINE** key when the Wireless Telephone is off hook. If the > icon is on, additional appearances can be displayed by repeatedly pressing the **LINE** key. The line is selected by pressing the number key corresponding to the number to the left of the "=" in the menu. The line does not have to be on the current display to be selected.

The Wireless Telephone has two volume levels, low and high. You can set your low volume level by pressing **FCN** while your Wireless Telephone is on-hook, and selecting a volume **1** through **8**. While you are talking on the Wireless Telephone, press **VOL** once to switch your volume level from low to high and vice versa. The Wireless Telephone will reset to the low volume when powered off.

Press **FCN** followed by a character **(1-4**, and ***** or **#**) while off-hook to access the feature options programmed in your Wireless Telephone template.

Function Key Strokes	Fill In Your Feature Settings
FCN + 1	Mute
FCN + 2	Last Number Dialed
FCN + 3	Transfer
FCN + 4	Conference
FCN + *	
FCN + #	

NOTE: For example, if **FCN+*** *corresponds to an abbreviated dialing button press* **START** *and* **FCN+*.** *The phone will then dial the number corresponding to that abbreviated dialing button.*

For information on Battery Pack charging and setting user preferences, see the Avaya™ 3606 Wireless IP Telephone User Guide.

3606 Wireless IP Telephone

On/Off	Press and hold **PWR**. Two chirps on, one chirp off
Make a call	Press **START** to get dial tone.
Hang up	Press **END**. Be sure to do this at the end of each call.
Answer call	Press **START**. Line indicator comes on steady when the call is answered.
Answer second call	Press **HOLD** to put your current call on hold, or **END** to hang up. Press **LINE** + the digit that is flashing.
Hold	Press **HOLD**
Take off Hold	Press **LINE** followed by the digit for the line on hold, which will be flashing.
Function	Pressing **FCN** while off hook allows you to scroll through menu screens.
User Options	Press **FCN** while on hook to change handset settings.
Adjust Volume	Press **VOL** while in a call to toggle between base and louder level
	Status/Tone Indicators
NO SVC Alarm / Restore	An alarm sounds when the Wireless Telephone cannot receive or place calls. You may be outside of the coverage area. Walk back into the covered area. A restore tone indicates service is re-established.
BATT Beep	Your Battery Pack charge is low. Your Battery Pack needs to be recharged or replaced.
MSG	You have a voice mail message.